


# User's Manual

## How to install the liner rewinder module for the LF140e




For the most recent version of this manual  
please visit [dtm-print.eu/manuals](http://dtm-print.eu/manuals)



Release the liner rewinder module from the packaging straps.


Remove the outer disk from the unwinder core (picture on left) and screw it onto liner rewinder's core.

The screws are inside the user manual slip.





The liner rewinder module is ready to be installed on LF140e






Using the supplied allen key, remove the four allen screws from LF140e lateral side



On the liner rewinder module, remove the 6 screws as shown in the picture. Than it will possible to keep out the cover.







Place the liner module in correspondence to the designed holes on LF140e lateral side and secure it in place using the four allen screws. Ensure that the plug is connected properly.

**ATTENTION.**

***Make sure to the liner module is vertically aligned with the LF140e as shown below.***



Close the module with its own cover and screw it down.

DTM Print GmbH  
Mainzer Strasse 131  
65187 Wiesbaden  
Germany  
Tel.: +49 611 92777 0  
Email: [sales@dtm-print.eu](mailto:sales@dtm-print.eu)  
[dtm-print.eu](http://dtm-print.eu)

